

# IMPORTANT SAFEGUARDS AND CAUTIONARY INFORMATION

## SAVE THESE INSTRUCTIONS

### FOR YOUR SAFETY, CAREFULLY READ ALL INSTRUCTIONS BEFORE OPERATING YOUR NUTRIBULLET.

#### ELECTRICAL SAFETY

When using any electrical appliances, basic safety precautions should always be observed, including the following:

- Caution! To avoid risk of electric shock, never immerse the cord, plug, or power base of blender in water or other liquids.
- This appliance has a polarized plug (one prong is wider than the other) to reduce the risk of electric shock. This plug will correctly fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. **Do not modify the plug in any way.**
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.

- **DO NOT USE THIS PRODUCT WITH ANY TYPE OF ADAPTOR OR VOLTAGE CONVERTER DEVICE. THIS UNIT IS MANUFACTURED IN COMPLIANCE WITH US AND CANADIAN ELECTRICAL STANDARDS AND PLUG TYPES.**
- **USE OF ADAPTERS AND CONVERTERS IS CONSIDERED AN UNAUTHORIZED MODIFICATION OF THE PRODUCT AND AS SUCH WILL VOID THE WARRANTY. USE OF THIS PRODUCT IN LOCATIONS WITH DIFFERENT ELECTRICAL SPECIFICATIONS MAY RESULT IN DAMAGE TO THE PRODUCT.**
- **UNPLUG THE NUTRIBULLET WHEN IT IS NOT IN USE. MAKE SURE THE POWER BASE IS UNPLUGGED BEFORE ASSEMBLING, DISASSEMBLING, ADDING ADDITIONAL PARTS, OR CLEANING.**

- Do not pull, twist, or damage the power cord.
- Do not allow the cord to hang over the side of the counter or table.
- Do not allow cord to touch hot surfaces, including stove.
- Periodically inspect cord and plug for damage. Do not operate any appliance with a damaged cord or plug. If the appliance malfunctions or is dropped or damaged in any manner, discontinue

use. Contact Customer Service for assistance in obtaining a replacement.

- Avoid contact with moving parts.
- Keep hands and utensils away from the cutting blade while chopping or blending food to reduce the risk of severe personal injury or damage to the device. A scraper may be used, but only when the blender/food chopper is not running.
- **NEVER LEAVE THE NUTRIBULLET UNATTENDED WHILE IT IS IN USE.**
- **CLOSE SUPERVISION IS NECESSARY WHEN ANY APPLIANCE IS USED BY OR NEAR CHILDREN.**
- To prevent overheating, never allow the motor to run for more than **one minute** at a time, as it can cause permanent damage to the motor. If the motor stops working, **unplug the Power Base and let it cool for an hour** before attempting to use it again. Your NUTRIBULLET has an internal thermal breaker that shuts off the unit when it overheats. The Power Base will reset when the unit is unplugged and the thermal breaker cools down.
- To reduce the risk of injury and leakage, make sure the blade base is securely screwed onto the cup before placing it on the Power Base and operating the appliance.
- Do not use NUTRIBULLET outdoors if exposed to inclement weather elements such as rain or other wet conditions.
- **Blades are sharp. Handle carefully.**
- **NEVER INSERT BLADE INTO THE POWER BASE WITHOUT FIRST ATTACHING THE CUP.**
- Check gasket to make sure it is completely seated in the cross blade or flat blade unit before each use.
- The NUTRIBULLET is not intended for use in microwave ovens. Do not place the NUTRIBULLET Cups, Power Base or any accessories in a microwave as this may result in damage to the appliance.
- To reduce the risk of personal injury or damage to the device, keep hands and utensils away from the cutting blade.
- Never blend carbonated beverages. Built-up pressure from released gases can cause container to burst, resulting in possible injury.
- Do not put hot liquids in any of the blending vessels before blending. Start with cool or room temperature ingredients. Heated ingredients can create internal pressure in a sealed blending vessel, which may erupt on opening and cause thermal injury.
- Do not run the NutriBullet when the cups are empty which can damage the unit.
- CAUTION! Friction from the rotating blade can cause ingredients to heat and generate internal pressure in the sealed vessel. Do not continuously operate for more than one minute. If the vessel

is warm to touch, allow to cool before carefully opening pointed away from your body.

- Never permit any blended mixture to sit inside a sealed vessel without first releasing internal pressure.
- Do not allow blended mixtures to sit for long periods in a sealed container. The sugars in the fruit and vegetables can ferment, causing pressure to build up and expand in the vessel which can cause ingredients to burst and spray out when moved or opened.
- Never use the NutriBullet with the Extractor Blade to Blend without liquid as doing so may damage the blade.
- The cyclonic action of your NutriBullet requires the use of liquids to make NutriBlasts and other nutritious beverages. It is not intended to be used as an ice crusher, and not without liquids. To make a delicious cold NutriBlast, we suggest that you use frozen fruit and chilled liquids. Alternatively, you may add crushed ice, up to 25% of the total cup volume, with water or other liquid filled up to the "MAX--" line. Do not crush ice or other hard items without liquid, as such prolonged use may dull or damage your blades. Always inspect your blades before each use.
- Never remove cup/blade assembly from the power base until the motor comes to a complete stop. Removing the cup/blade assembly while power base is still running may cause damage the blade coupling or motor gear.
- To stop the motor, twist to release the cup if in lock mode and stop pressing cup/blade assembly down if in pulse mode and wait for motor to power down completely.

### **WARNING: VENTILATION CAUTION**

- **Always operate the NUTRIBULLET on level surface, leaving unobstructed space beneath and around the power base to permit proper air circulation. Slots and openings on the bottom of the product are provided for ventilation to ensure reliable motor operation and to prevent over-heating. Warning: To prevent fire hazard, power base openings should be free of dust or lint and never obstructed with flammable materials such as newspapers, tablecloths, napkins, dishtowels, or place mats.**

**SAVE THESE INSTRUCTIONS  
FOR HOUSEHOLD USE ONLY**

### **WARNING!**

- **IF YOU ARE TAKING ANY MEDICATION, ESPECIALLY CHOLESTEROL-LOWERING MEDICATION, BLOOD THINNERS, BLOOD PRESSURE DRUGS, TRANQUILIZERS, OR ANTIDEPRESSANTS, PLEASE CHECK WITH YOUR DOCTOR BEFORE CONSUMING ANY OF THE NUTRIBLAST RECIPES.**
- **THE FOLLOWING LIST OF SEEDS AND PITS CONTAIN CHEMICALS THAT RELEASE CYANIDE INTO THE BODY WHEN INGESTED. DO NOT USE THE FOLLOWING SEEDS AND PITS IN THE NUTRIBULLET:**
  - **APPLE SEEDS**
  - **CHERRY PITS**
  - **PEACH PITS**
  - **APRICOT PITS**
  - **PLUM PITS**

### **CLEANING SAFEGUARDS**

- **RINSE BLADES (AND CUPS) IMMEDIATELY AFTER USE TO PREVENT DEBRIS FROM DRYING AND STICKING TO VESSELS - IF NECESSARY, USE A DISH BRUSH TO LOOSEN ANY DEBRIS.**
- **HAND WASH ONLY WITH MILD DISH SOAP AND WARM WATER (NOT HOT).**
- **DRY IMMEDIATELY.**
- **FOR TOUGH DEBRIS, FILL THE CUP ½ FULL WITH WARM (NOT HOT), MILD SOAPY WATER. THEN, SIMPLY TWIST ON THE BLADE, POP IT ON THE BASE AND GIVE IT A RUN FOR 30-45 SECONDS. FOLLOW UP WITH A QUICK BRUSH.**
- **DO NOT PUT THE BLADES IN THE DISHWASHER AS ELEVATED TEMPERATURES CAN DAMAGE GASKETS. SIMPLY HAND WASH WITH WARM, MILD SOAPY WATER.**
- **THE NUTRIBULLET CUPS CAN BE WASHED ON THE TOP RACK OF THE DISHWASHER USING THE NORMAL (NOT SANITIZE) CYCLE. THE NUTRIBULLET CUPS AND BLADES SHOULD NOT BE IMMERSSED IN BOILING WATER FOR ANY REASON AS THIS WILL WARP THE PLASTIC AND DAMAGE THE GASKET.**
- **WHEN WASHING BLADES, DO NOT ATTEMPT TO REMOVE THE GASKET RING. SIMPLY HAND WASH THE BLADES IN WARM, MILD SOAPY WATER. ATTEMPTED REMOVAL OF THE GASKET MAY PERMANENTLY DAMAGE THE BLADE CONFIGURATION AND CAUSE LEAKAGE. IF IN TIME A GASKET BECOMES LOOSE OR DAMAGED, PLEASE CONTACT CUSTOMER SERVICE FOR A REPLACEMENT NUTRIBULLET BLADE HOLDER AT: 1-855-346-8874.**

# CLEANING THE NUTRIBULLET

Everyone hates cleaning up, which is just one more reason the NUTRIBULLET is such a wonderful time saver.

**WARNING:**  
**ALWAYS UNPLUG THE NUTRIBULLET WHEN CLEANING OR ASSEMBLING.**

## Washing the NUTRIBULLET

Cleaning the NUTRIBULLET is so easy... simply place any of the pieces (except for the Power Base and blade holders) on the top shelf of the dishwasher or hand wash with warm soapy water and rinse.

**WARNING:**  
**DO NOT WASH THE BLADES IN THE DISHWASHER. THE NUTRIBULLET CUPS CAN BE WASHED IN THE DISHWASHER AND SHOULD BE WASHED ON THE TOP RACK OF THE DISHWASHER USING THE NORMAL (NOT SANITIZE) CYCLE. THE NUTRIBULLET CUPS AND BLADES SHOULD NOT BE IMMERSSED IN BOILING WATER FOR ANY REASON AS THIS WILL WARP THE PLASTIC AND DAMAGE THE GASKETS.**

## STUBBORN CLEANUP

If ingredients dry inside the NUTRIBULLET, make your cleanup a snap by filling the cup about 2/3 full with warm soapy water and screw on the Extractor Blade. Place the cup assembly on the NUTRIBULLET, Power Base for about 20-30 seconds. That will loosen the stuck ingredients, and with a light scrub, you'll be all done.

## CLEANING THE NUTRIBULLET POWER BASE

For the most part the Power Base doesn't really get dirty, but if you neglect to twist the blade on to the cup tightly, liquids can leak out and get into the base and activator buttons.

Here's how to clean it up.

**Step 1:** The most important thing is to UNPLUG the Power Base before cleaning!

**Step 2:** Use a damp rag to wipe down the inside and outside of the Power Base.

- **NEVER SUBMERGE THE POWER BASE IN WATER OR PLACE IT IN THE DISHWASHER.**
- Never put your hands or utensils near the moving blade and never use your hands or utensils to press the activator buttons down while the Power Base is plugged in.

**SAVE THESE INSTRUCTIONS**  
**FOR HOUSEHOLD USE ONLY**