



INSTRUCTION BOOKLET

**2 TIER HEATED AIRER**



Model: 25210

# **DRY:SOON DELUXE 2 TIER HEATED AIRER**

Thank you for choosing the Dry:Soon Deluxe 2 Tier Heated Airer.

Please take a little time to read this booklet before you use your machine and keep it in a safe place for future reference.

You can dry your washing quickly and easily no matter what the weather with the Deluxe 2 Tier Heated Airer – it costs just pennies to run and is kinder to clothes than tumble drying.

The timer allows you to set your airer to switch on and off up to 12 hours ahead.

The open shelves are really easy to fill and so versatile, just position them to suit your needs: as well as drying t-shirts, socks and smalls over the rungs, you can lay delicate items flat to avoid stretching. With hold-together clips and a cord tidy, it stores away neatly when not in use.

Here at Lakeland, our award-winning family-owned business still offers the same excellent quality, value for money and exceptional customer service as when we founded the company back in the 1960s.


Our products are hand-picked and thoroughly tested so you can be sure that everything you purchase will be a pleasure to use for many years to come.

## **CONTENTS**

Product features.....	3
Safety cautions.....	4-5
Setting up the airer and using for the first time .....	6-7
Instructions for use .....	8
Using the timer .....	9-12
Storing your airer .....	13
Frequently asked questions.....	13
Electrical connections .....	14
Recycling your electricals .....	14

# PRODUCT FEATURES


- 1. Heated bars
- 2. Front supports
- 3. Back supports
- 4. Clips
- 5. Hold-together clips
- 6. Carry handle
- 7. Cord and plug
- 8. Plug tidy
- 9. Display
- 10. MODE button
- 11. HOUR button
- 12. On/off switch



## **SAFETY CAUTIONS**

Carefully read all the instructions before using the appliance and keep in a safe place for future reference. Always follow these safety cautions when using the appliance to avoid personal injury or damage to the appliance. This appliance should be used only as described in this instruction book.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised.
- Make sure your electricity supply matches the voltage shown on the appliance.
- Ensure all packaging materials and any promotional labels or stickers are removed from the appliance before the first use.
- Always inspect the appliance before use for noticeable signs of damage. Do not use if damaged or has been dropped. In the event of damage, or if the appliance develops a fault contact the Lakeland customer care team on 015394 88100.
- Always use the appliance on a dry, level surface.
- Unplug from the mains when not in use. To disconnect, turn the socket to “off” and remove the plug from the mains socket.
- Do not use any accessories or attachments with this appliance other than those recommended by Lakeland.
- To protect against fire, electric shock or personal injury, do not immerse cord, plug or lid in water or other liquids.
- Avoid contact between the lead and hot surfaces. Keep the ailer plug and lead away from ovens, electric and gas burners, flames and water sources.
- For indoor use only.
- For domestic use only.
- This appliance should be used for airing clothes as described within the instructions for use that accompany it.
- Always ensure that your hands are dry before removing the plug from the mains socket. Never pull the plug out of the mains socket by its lead or carry the ailer by its lead.


- Do not allow the lead to be compressed or curled, or touch sharp edges.
- Do not connect this appliance to an external timer or remote control system.
- An extension cable may be used with care. The electrical rating of the cable should be at least as great as the appliance.
- This appliance complies with the basic requirements of Directives 2014/30/EU (Electromagnetic Compatibility) and 2014/35/EU (Low voltage Directive).
- **WARNING:** A cut off plug inserted into a socket is a serious safety (shock) hazard. Ensure the cut off plug is disposed of safely.
-  **CAUTION:** The plastic bags used to wrap this appliance or the packaging may be dangerous. To avoid risk of suffocation, keep these bags out of reach of babies and children. These bags are not toys.
- Always switch off and unplug the Deluxe 2 Tier Heated Airer after use, leaving it to cool down completely before closing it to store. Do not wind the power cord around the airer.
- Ensure the airer is folded out securely before loading it with laundry and switching it on.
- When opening and closing the airer, never use force. The mechanisms should move freely and easily. Keep fingers away from the folding parts.
- Do not overload the airer, the maximum load of the airer is 10kg. Load evenly across the surface to avoid the airer tipping over.

## SETTING UP THE AIRER AND USING FOR THE FIRST TIME

1. Carefully unpack the airer and remove all the packaging materials.
2. The airer needs to be set up on a dry level surface near a socket, with plenty of space around it.
3. Stand the airer upright, with the control panel facing you.




4. Unclip the front supports from the hold-together clips, open them out to the left and right at a 90 degree angle.



Open out the supports to 90°.


5. Repeat on the opposite side for the back supports.



- Now fold out the heated bars. Start on one side of the ailer. Raise the bottom bar upwards, and lower it to sit securely inside the clips on each side.

**WARNING**

Do not force the shelf beyond the level indicated by this dotted line, approximately 2.5cm (1") above the clip. When opening and closing the ailer, never use force. The mechanism should move freely and easily. Keep fingers away from folding parts.



Clips

- Repeat for the top heated bars.
- Repeat on the other side of the ailer.

**For smaller loads and confined spaces, you can open and use one side of the ailer.**

You can hang t-shirts, socks and smalls, and lay delicate items flat to avoid stretching.




# INSTRUCTIONS FOR USE

## WARNING


Ensure the airer is folded out securely before loading it with laundry and switching it on.

Do not overload the airer, the maximum load of the airer is 10kg. Load evenly across the surface to avoid the airer tipping over.

1. Plug the airer into the socket and switch on.
- 2 Press the **on/off** switch. The airer will beep, the screen will illuminate and display '**ON**' to show the airer is heating.



3. Press the **on/off** switch again to turn off, the screen will go blank. Switch off at the socket and unplug. Leave the airer to cool down completely before closing it to store.






## USING THE TIMER


To cancel the timer while you are setting it or mid-cycle, press the **on/off** switch to turn the ailer off.

### SETTING THE TIMER TO SWITCH THE AIRER **OFF**

1. You can set the timer to switch the ailer **OFF**, up to 12 hours ahead.
2. With the ailer switched **ON**, press the **MODE** button twice. The display will read '**H**'.




3. Press the **HOUR** button repeatedly to select how many hours you would like the ailer **ON** until it switches **OFF**, from 1 hour to 12.
4. When the display shows '**H**' and the number of hours you would like, press the **MODE** button to set the timer.
5. The display will show a flashing '**H**' and the number of hours the ailer will be **ON** and heating for.




6. The hours will count down on the display until the ailer switches **OFF**.
7. When the cycle has finished the timer will beep five times, the display will read '**O**' and the **on/off** switch will illuminate until you press it again to fully switch off the ailer.
8. Switch off the socket and unplug.

## SETTING THE TIMER TO SWITCH THE AIRER **ON**

1. You can set the timer to switch the airer **ON** up to 12 hours ahead.
2. With the airer switched **ON**, press the **MODE** button once. The display will read '**P**'.




3. Press the **HOUR** button repeatedly to select how many hours you would like the airer **OFF** until it switches **ON**, from 1 hour to 12.
4. When the display shows '**P**' and the number of hours you would like, press the **MODE** button twice to set the timer.
5. The display will show a flashing '**P**' and the number of hours until the airer switches **ON**.




6. The hours will count down on the display until the airer switches **ON**. The display will then show '**ON**'.
7. The airer will stay **ON** until you press the **on/off** switch to turn it **OFF** manually. You will need to remember to switch the airer **OFF**.
8. Switch off at the socket and unplug.

## SETTING THE TIMER TO SWITCH THE AIRER **ON**, THEN SWITCH **OFF**

1. You can set the timer to switch the airer **ON** up to 12 hours ahead, and then heat for up to 12 hours and switch **OFF**.
2. With the airer switched **ON**, press the **MODE** button once. The display will read '**P**'.




3. Press the **HOUR** button repeatedly to select how many hours you would like the airer **OFF** until it switches **ON**, from 1 hour to 12.
4. When the display shows '**P**' and the number of hours you would like, press the **MODE** button once. The display will read '**H**'.
5. Press the **HOUR** button repeatedly to select how many hours you would like the airer **ON**, from 1 hour to 12.




6. When the display shows '**H**' and the number of hours you would like, press the **MODE** button once to set the timer.

7. The display will show a flashing '**P**' and the number of hours until the ailer switches **ON**. The hours will count down on the display.



8. When the ailer has started heating, the display will show a flashing '**H**' and the number of hours until the ailer switches **OFF**. The hours will count down on the display.



9. When the cycle has finished the timer will beep five times, the display will read '**O**' and the **on/off** switch will illuminate to remind you to press it again to fully switch off the ailer.
10. Switch off at the socket and unplug.

## STORING YOUR AIRER

1. Leave the airer to cool down completely before closing it to store.
2. Close the airer by folding down the heated bars on each side, top and bottom. Then fold in the back and front supports, clipping them into the hold-together clips to store it flat until your next use.
3. Store the plug inside the plug tidy.



4. Move the airer using the carry handle.
5. Do not wind the power cord around the airer.
6. Check the parts for wear or damage after every few uses.

## FREQUENTLY ASKED QUESTIONS

**Question:** Why is my Deluxe 2 Tier Heated Airer not heating up?

**Answer:** It may not be switched on. Check the airer is plugged in, switched on at the socket and the on/off switch is pressed and illuminated.

# ELECTRICAL CONNECTIONS

## THIS APPLIANCE MUST BE EARTHED

The appliance is fitted with a fused three-pin plug to BS1363 which is suitable for use in all homes fitted with sockets to current specifications.

## CHANGING THE 3 AMP FUSE

Use a 3 amp BS1362 fuse. Only BSI or ASTA approved fuses should be used. If you are unsure which plug or fuse to use, always refer to a qualified electrician.

**Note:** After replacing or changing a fuse on a moulded plug which has a fuse cover, the cover must be refitted to the plug; the appliance must not be used without a fuse cover. If lost, replacement fuse covers can be obtained from an electrical shop. This appliance complies with the following EU Directives: 2014/35/EU (Low Voltage Directive) and 2014/30/EU (EMC Directive).

## RECYCLING YOUR ELECTRICALS

Along with many other high street retailers, Lakeland has joined a scheme whereby customers can take their unwanted electricals to recycling points set up around the country.

Visit [www.recycle-more.co.uk](http://www.recycle-more.co.uk) to find your nearest recycling point.





**Lakeland**

Alexandra Buildings, Windermere, Cumbria, UK LA23 1BQ  
Tel: +44(0)15394 88100 [www.lakeland.co.uk](http://www.lakeland.co.uk)