

# Assembly Instructions – Insect Panel Curtain

**These instructions are to be used in conjunction with the picture diagrams.  
Please read the Care and Maintenance instructions overleaf before use.**

The curtain brackets are designed to be screwed to the door frame, which is the most secure method of fixing, however we have also provided adhesive pads as an alternative method. The adhesive pads are designed for use on PVC frames, but should also bond to other smooth surfaces such as wood or metal. The adhesive pads may need replacing each year. Please read the details below - **Preparing surfaces to apply adhesive pads\***.

**The curtain should be fitted on the opposite side to the way the door opens.**

1. Measure the width of your door frame and include as much overlap as you would like.
2. Separate the bracket sections parts **X** and **Y**.
3. Attach the bracket parts **X** to the right and left corners of the door frame and the parts **Y** evenly in between.  
**If you choose to stick the brackets to the frame please allow 24 hours for the adhesive to bond before putting any weight or pressure on the brackets. We also recommend adding a bead of clear silicon (not supplied) around the bracket to provide extra bonding.**
4. Cut the tube and the track to width required (making sure you cut it straight).
5. Use the 3 yellow sticky tabs to hold the tube steady during stages 6, 7 and 8.
6. Peel the backing paper off the tube.
7. Overlap the panels to the width required and lay them over the sticky tape on the tube.
8. Place the track on top of the tube and mesh; click into place making sure that the lip is at the top. Trim any excess mesh at the top with a Stanley knife. Do not trim the bottom of the panels yet – see stage 10.
9. Hang the curtain, by fitting the lip of the track on the ridge of the brackets **X** and **Y**.
10. The panel and weight must swing freely above the floor or threshold. Cut the mesh panels to a height of 22mm above the floor or threshold; when the weight is attached this will allow a 5 – 7mm clearance. Please be aware that panels are not supplied to a standard length.
11. Remove the curtain from the brackets and fit the weights while the curtain is lying flat - apply gentle outward pressure to outer brackets **X**. Diagram 11 shows the correct position of the mesh within the weight.  
**\*It is important to ensure that the mesh is properly positioned so that the weights grip the mesh panels firmly. If they do not grip the panels firmly the weights may fall off, possibly tearing or fraying the mesh.** The weights consist of two halves with small spikes and locating holes on their inside faces. The two halves grip together through the mesh, with the spikes locating into their opposite holes.  
**To fit the weights:** Separate the two halves and position the cut edge of the mesh panel up to the line of three locating lugs on one half. Ensure the mesh does not overlap the line or the lugs, as this will stop the weights from gripping the mesh panel. Position the other half of the weight over the first half and press firmly together.
12. Secure the two halves of the weight together with the rubber buttons.

## **To remove curtain**

Release track and panels by applying gentle outward pressure to outer brackets **X**.

## **\*Preparing surfaces to apply adhesive pads**

If you decide to use the adhesive pads instead of screwing the brackets to the door frame, please ensure the surface is **perfectly clean, dry and free from dust, grease and finger prints**. Remove the pads from the backing paper taking care not to touch or otherwise soil the adhesive surface. When the brackets have been stuck in place please allow 24 hours for the adhesive and silicone to bond before putting any weight or pressure on the brackets.