
# **B-Warm**

Instructions

 $homeglow^{m}$ 



#### **Product Features**

- 1 Seat Cover
- 2 Attached Velcro Belt
- 3 Adjustable Back
- 4 Corner Straps
- 5 Buckle
- 6 L-shaped Corner Bar and Velcro Belt


### Assembling your seat cover

- Lay the Seat Cover (1) flat, blue side facing upwards
- Take the Buckle (5), slot it through the top of the seat cover (1), fold the top of the seat cover over to close the velcro
- Take the Adjustable back (4), with the velcro side up, and slot the top through the other side of the Buckle (5), fold down and close the velcro

Your seat cover can be fitted around chairs with loose cushions, or used on top of chairs without cushions or with fixed cushions.

## Fitting your seat cover to chairs with removable cushions

- Take the seat cushion off your chair
- Take the L-shaped Corner Bar and Velcro Belt (6), position the L-shaped corner bar on your chair, so it sits in the join of the seat base and the seat back. The longest side should be on the base and the shortest on the back. Undo the Velcro belt.
- Place the cushion back on your seat on top of the L-shaped Corner Bar (6), tension the Velcro belt around the far end of the cushion and close.
- Place the Seat Cover (1) blue side up, along the length of the chair, with the Adjustable Back (3) hanging down the back of the chair.
- Press the Seat Cover (1) down to attach it to the L-shaped Corner Bar and Velcro Belt (6)
- Undo the Attached Velcro Belt (2) on back of the seat cover, and wrap it around the front end of the seat cushion. Tension the velcro strap and close.
- Undo the velcro on the two Corner Straps (4)
- Wrap the two Corner Straps (4) around the two back legs of the chair, tension and close.
- Finally, undo the Velcro attaching the Adjustable Back (3) to the Buckle (5), and pull down the plain side (without velcro), to tighten the cover, close the Velcro.



# Fitting your seat cover to chairs without cushions or with fixed cushions

- Place the Seat Cover (1) blue side up, along the length of the chair, with the Adjustable Back (3) hanging down the back of the chair.
- Undo the Attached Velcro Belt (2) on the back of the Seat Cover (1), and wrap it around the front end of the seat of the chair. Tension the velcro strap and close.
- Take the L-shaped Corner Bar and Velcro Belt (6), undo the velcro and remove the L-shaped Corner Bar.
  Wrap the Velcro Belt around the far end of the seat of the chair. Press the Seat Cover (1) down on top to attach.
- Undo the velcro on the two Corner Straps (4)
- Wrap the two Corner Straps (4) around the two back legs of the chair, tension and close.
- Finally, undo the velcro attaching the Adjustable Back (3) to the Buckle (5), and pull down the plain side (without velcro), to tighten the cover, close the Velcro.

### Operating:

- 1. Ensure cable with controller is connected firmly to heated seat cover socket.
- 2. Insert plug to mains (220v) power supply and switch
- 2. Ensure cables are positioned safely to avoid hazards.
- Press controller button to select one of the four settings indicated by coloured LEDs. Lowest setting is green, highest red. To switch off or set another setting repeatedly press button to select. Heat setting will be fast to respond and will hold temperature selected very accurately.
- 4. Unit will switch off automatically after 4hours and can be reset for further 4 hour period.

### **Technical Specification:**

- 220v 50Hz AC
- Output 10W/45W
- Precision temperature control
- One button control 4 settings
- CE certified to EN60335-2-17:2013 and EN62233
- Auto shutdown in event of any failure
- Machine washable cover for hygiene
- 1 year warranty

#### Maintenance:

Seat cover is low maintenance and can be wiped with a dampened cloth to remove marks. It can be washed in a washing machine at 30C (synthetics); remove the loose plastic items and disconnect power cable with controller from cover by pressing retaining clips and withdrawing. DO NOT WASH CONTROLLER. Do not tumble dry. It should be left to dry on a rack or on a flat surface. Reassemble when dry.

### Warranty:

1 year warranty subject to there being no evidence of misuse.

To find out more about the B-warm heated seat cover please visit our website at www.homeglowproducts.co.uk.



Homeglow Products Ltd., Mayfield, Usk, Monmouthshire NP15 1SY

Tel: 01291 672974 Email: info@homeglowproducts.co.uk