

# *the Citrus Press*

Instruction Booklet



800CPUK

**Sage**<sup>™</sup> by heston  
blumenthal<sup>®</sup>

- 3** We recommend safety first
- 7** Getting to know your new appliance
- 8** Assembling your new appliance
- 10** Operating your new appliance
- 12** Disassembling your new appliance
- 13** Care & Cleaning
- 14** Hints & Tips
- 15** Troubleshooting

At Sage™ by Heston Blumenthal® we are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer, foremost in mind. In addition we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions.

## **IMPORTANT SAFEGUARDS**

### **READ ALL INSTRUCTIONS BEFORE USE AND SAVE FOR FUTURE REFERENCE**

- Before using for the first time please ensure that your electricity supply is the same as shown on the rating label on the underside of the appliance. If you have any concerns please contact your local electricity company.
- Your Sage™ by Heston Blumenthal® appliance includes a BS 13 amp moulded mains plug on the supply cord.
- Should you need to change this plug, please complete the rewiring as follows (after safe disposal of the moulded plug).
  - Wires are coloured as follows:
    - Blue = Neutral
    - Brown = Live
    - Green & Yellow = Earth
  - As the colours of the wire may not correspond with the coloured markings which identify the terminals in your plug, please refer to the following:
    - The Blue wire must be connected to the terminal which is marked 'N'.
    - The Brown wire must be connected to the terminal which is marked with the letter 'L'.
    - The Green & Yellow wire must be connected to the terminal which is marked with the letter E or the earth symbol  $\perp$ .
- Please note that a cut off plug inserted into a socket is a serious danger risk
- Please note that if a 13 amp plug is used, a 13 amp fuse should be used.

## WE RECOMMEND SAFETY FIRST

- Carefully read all instructions before operating and save for future reference.
- Before use fully unwind the power cord.
- Always use the Citrus Press on a dry, level surface.
- Remove any promotional stickers before using the Citrus Press.
- Always make sure the Citrus Press is properly assembled before connecting the plug and switching on at the power outlet and switching ON the ON/OFF button on the appliance. The appliance will not operate unless properly assembled.
- Always switch the appliance OFF at the ON/OFF button, then switch off at the power outlet and remove the plug if the appliance is left unattended, if not in use, if moved or dismantled for cleaning and when storing.
- Do not let the cord hang over the edge of a table or counter, touch hot surfaces, or become knotted.
- Do not place this appliance on or near a hot gas or electric burner, or where it could touch a heated oven.
- Do not leave the appliance unattended when in use.
- Use caution when operating the appliance – do not place hands or fingers near moving or rotating parts.
- Avoid placing hands or fingers near Juicing Press Arm mechanism at rear of Motor Base when moving Juicing Press Arm into the upright position.
- This appliance is not intended for use by young children or infirm persons without supervision.
- Do not immerse power cord or motor base in water or any other liquid.

## SAVE THESE INSTRUCTIONS

## WE RECOMMEND SAFETY FIRST

- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.
- Any maintenance other than cleaning should be performed at an authorised Sage™ by Heston Blumenthal® Service Centre.
- Strictly follow cleaning and care instructions.
- To protect against electric shock do not immerse the power cord, power plug or appliance in water or any other liquid.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use the appliance if power cord, power plug or appliance becomes damaged in any way. If damaged or maintenance other than cleaning is required, please contact Sage™ by Heston Blumenthal® Customer Service on 0844 334 5110 or go to [sageappliances.co.uk](http://sageappliances.co.uk)

## IMPORTANT SAFEGUARDS FOR ALL ELECTRICAL APPLIANCES

- Fully unwind the power cord before use.
- Do not let the power cord hang over the edge of a bench or table, touch hot surfaces or become knotted.

## WE RECOMMEND SAFETY FIRST

- This appliance is for household use only. Do not use this appliance for anything other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors. Misuse may cause injury.
- Avoid placing hands or fingers near the juice press arm at the rear of the motor base when moving it into the upright position.
- The appliance is switched on when the power ON/OFF button is in the 'ON' position which will be illuminated in red.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children and user maintenance shall not be made by children unless they are age 8 years and above and supervised.

Keep the appliance and its cord out of reach of children aged less than 8 years.



The symbol shown indicates that this appliance should not be disposed of in normal household waste. It should be taken to a local authority waste collection centre designated for this purpose or to a dealer providing this service. For more information, please contact your local council office.

## GETTING TO KNOW YOUR NEW APPLIANCE



- A. Juice Press Arm**  
Patented juicing handle features a unique triple hinged arm to ensure downward pressure throughout the juicing process to maximize juice yield.
- B. Stainless Steel Filter**  
(dishwasher safe)
- C. Powerful Motor**  
Automatically starts when pressure is applied to the juicing cone.
- D. ON/OFF Button**
- E. Cord Storage**  
Wraps around and clips into position under motor base (not shown in picture).
- F. Soft Grip Handle**  
Makes juicing easy.
- G. Fruit Dome**  
Is easily removed for cleaning.  
(dishwasher safe)
- H. Die Cast Stainless Steel Juicing Cone**  
Uniquely finned and undulating cone extracts the maximum juice from all sizes of citrus fruit.  
(dishwasher safe)
- I. Juice Collector**  
Collects the juice to flow out the Juice Spout.  
(dishwasher safe)
- J. Juice Spout**  
Opens all the way for cleaning with anti-drip stop function.
- K. Double Stage Switching System**  
Juicer will NOT operate unless it is correctly assembled for safety and performance.

## ASSEMBLING YOUR NEW APPLIANCE

### ASSEMBLING THE CITRUS PRESS

1. Pull the juice press arm up and backwards, away from the motor base, until fully extended.



2. Place the juice collector onto the drive shaft on top of the motor base, ensuring the juice spout fits into the semi-circular groove at the front of the motor base.



3. Insert the stainless steel filter into the juice collector, aligning the indent with arrow in the bottom of the filter over the corresponding tab with arrow in the juice collector.



4. Place the juicing cone onto the drive shaft and press down lightly to lock the cone into position.





## ASSEMBLING YOUR NEW APPLIANCE

5. Insert the fruit dome onto the underside of the juice press arm by aligning the tab on top of the fruit dome with the hole in the juice press arm. Hold onto the juice press arm and press the fruit dome up and backwards until the dome locks into position.

### NOTE

The fruit dome is keyed, and can only be inserted in one way (this will ensure that it does not rotate through operation).



6. Ensure the anti-drip juice spout is pushed down into the pouring position.




7. Place a suitable sized glass or jug underneath the juice spout.

## OPERATING YOUR NEW APPLIANCE

1. Ensure the citrus press is correctly assembled and a glass or jug is placed under the juice spout before juicing commences.




2. Cut the citrus fruit in half by cutting across the fruit segments, rather than across the tip ends, to ensure more efficient juicing.



3. Plug the power cord into a 230V power outlet, then press ON/OFF button to ON.



4. Place a citrus fruit half, cut side down, onto the juice cone and push down lightly onto the spikes.



### NOTE

Some fruits, such as lemons and tangelos, have knobby tip ends which require trimming for better contact with the fruit dome.

## OPERATING YOUR NEW APPLIANCE

5. Grasp the soft grip handle and slowly lower the juice press arm and press down firmly until the fruit dome is in contact with the fruit skin. The motor will automatically start and the juicing cone will begin to rotate. The juice will be extracted from the fruit and flow through the juice spout into the glass. The pulp and seeds will collect in the stainless steel filter.



6. The Citrus Press juices very quickly so each fruit half will be juiced in a few seconds. To automatically stop the motor, lift the juice press arm up and backwards to its extended position.



7. Remove the used fruit from the juicing cone. Empty excess pulp and seeds from stainless steel filter as required. Repeat Steps 3-7 to continue juicing.

### NOTE

The stainless steel filter should be emptied when full with pulp and seeds. The filter can be emptied during juicing by turning the citrus press OFF at the ON/OFF button and carefully removing the juicing cone and filter. Clean and replace stainless steel filter and juicing cone before continuing to juice. Do not allow the stainless steel filter to overfill as this may prevent correct operation or damage the unit.

## DISASSEMBLING YOUR NEW APPLIANCE

### DISASSEMBLING THE CITRUS PRESS

1. Turn the Citrus Press OFF at the ON/OFF button, then unplug from the power outlet.



2. Pull the juice press arm up and backwards, away from the motor base, until fully extended. Close the anti drip spout by flipping it up.



3. With the arm in the down position, remove the fruit dome by pressing the button marked EJECT. Let the fruit dome drop onto the juicing cone.



4. Lift the juice collector from the motor body with the stainless steel filter, juicing cone and fruit dome still in place. Remove the cone and filter from the juice collector over a sink for easier cleaning. Follow recommended care and cleaning guidelines.



### STORAGE

Store the cleaned and reassembled Citrus Press in an upright position in a cool, dry place. Do not place any items on top of the Citrus Press while stored.

## CARE & CLEANING

- Always ensure that the Citrus Press is turned OFF at the ON/OFF button and the plug is removed from the power outlet before cleaning, disassembling, assembling and storing the appliance.
- Follow these instructions to clean all surfaces or parts that come into contact with food during juicing.
- For easy cleaning immediately after each use rinse removable parts under warm water to remove wet pulp. Allow parts to air dry before reassembling.
- For thorough cleaning after disassembling the appliance, all removable parts should be washed in hot soapy water or on the top shelf of the dishwasher. The motor base and juice press arm should be wiped with a soft, damp cloth. All parts should be dried thoroughly before reassembling.
- Store the cleaned and reassembled Citrus Press in an upright position in a cool, dry place. Do not place any items on top of the Citrus Press while stored.

### NOTE

Do not soak the stainless steel filter or other removable parts in bleach. Never immerse the motor base in water or any other liquid. Do not use harsh abrasives

### NOTE

Rinse or wash all removable parts immediately after use. Dried citrus pulp is difficult to remove and may stain. If any staining does occur, wipe the discoloured part(s) with undiluted dishwashing liquid, rinse and dry thoroughly.

### **THE INSIDE INFORMATION ON JUICE**

Although juice drinks are usually developed with flavor, texture and aroma at the forefront, the health benefits certainly add to the pleasurable taste experience. 70% of the nutrient content of fruit and vegetables is found in the juice. Liquids are an important part of a well balanced diet and fresh juice is an easy source of vitamins and minerals. Juices are rapidly absorbed into the blood stream therefore being the quickest way in which the body can digest nutrients. Citrus juice is renowned for its high content of Vitamin C and cold and flu fighting capabilities. Freshly extracted juices should be consumed just after they have been made to avoid vitamin content loss.

### **PURCHASING AND STORAGE OF FRUIT**

- Always use fresh fruit for juicing.
- Select fruit with firm, smooth skins and free of blemishes.
- Valencia oranges are ideal for juicing.
- Select medium sized grapefruits, lemons and limes for easier juicing.
- Citrus fruits can be stored at room temperature in a dry area.
- More juice is obtained from fruit stored at room temperature.

## TROUBLESHOOTING

POSSIBLE PROBLEM	EASY SOLUTION
<b>Will not work</b>	<ul style="list-style-type: none"><li>• Switch not in the ON position</li><li>• Juice Press Arm not lowered</li><li>• Juicing Cone or Fruit Dome not assembled properly</li><li>• Stainless Steel Filter not assembled properly</li></ul>

# Sage™ by Heston Blumenthal®

## Customer Service Centre

**Phone: 0844 334 5110**

**[www.sageappliances.co.uk](http://www.sageappliances.co.uk)**

**[customerservice@sageappliances.co.uk](mailto:customerservice@sageappliances.co.uk)**


### Register your product and get more from your purchase

Product registration takes only a few minutes and ensures both a record of your purchase and your warranty. Registration also makes it easier to get support and advice on any questions or issues that you might have in the future. If you wish, we can also send you free recipes and additional hints and tips on making the best of your appliance.

 Go to [www.sageappliances.co.uk](http://www.sageappliances.co.uk) and click on 'Product Registration'.

### What's on your mind?

Our constant aim is to improve the quality and features of our appliances. We welcome your comments and ideas in assisting our ongoing development.

 Go to [www.sageappliances.co.uk](http://www.sageappliances.co.uk) and click on 'Support'.

**Sage™** by heston blumenthal®

Registered in England & Wales No. 8223512. Due to continued product improvement, the products illustrated or photographed in this document may vary slightly from the actual product.

Copyright BRG Appliances 2012.

**800CPUK Issue - A12**