

Dreamland



HEAT ON THE GO

CORDLESS HEAT POD


TYPE M2701



Operating instructions

DIAGRAMS

[A] Product Overview



Features:

- 1. Mains Plug
- 2. Specification
- 3. On/Off Switch
- 4. Heat pod connector
- 5. Charger
- 6. Led charging display
- 7. Heat pod cover
- 8. Store charger when not in use.

[B] Charging Heat Pod



[C] Always use inside cover



[D] 5 minutes fast charge up



SPECIFICATIONS

Dreamland

TYPE M2701 220-240 V 50/60 Hz 300-365 W





INSTRUCTIONS FOR USE OF THE CORDLESS HEATPOD

Dear customer, DREAMLAND thanks you for having purchased this product. We are certain you will appreciate the quality and reliability of this appliance, designed and manufactured with customer satisfaction in mind. This instruction manual has been drawn up in compliance with the European Standard EN 62079.

IMPORTANT INSTRUCTIONS KEEP FOR FUTURE USE



IMPORTANT! Instructions and warnings for safe use



Before using the Heat Pod, carefully read the instructions and in particular the safety warnings, which must be complied with. Keep this manual and illustrative guide with the appliance for future consultation. Should you pass the appliance on to another user, make sure to also include this documentation.

(i) NOTE: should certain parts of this booklet be difficult to understand or should doubts arise, contact the company before using the product, at the address indicated on the last page.

CONTENTS





Safety warnings	page 2
Symbols	page 3
Product overview and features	page 4
Using the Heat Pod	page 4
Cleaning and maintenance	page 5
After sale assistance	page 5
Regular servicing	page 6
Warranty	page 6
Disposal	page 7
Diagrams	page I
Specifications	page I

SAFETY WARNINGS

- After unpacking, make sure that the heat pod is intact with no visible signs of damage caused during transport. Should you have any doubts, please do not use the appliance and contact the authorised service centre.
- Do not let children play with the packaging! Keep the plastic wrapping out of the reach of children - risk of suffocation!
- Before connecting the appliance, please make sure that the voltage data indicated on the specification data correspond to those of the mains voltage. The specification data are found on the appliance.
- This appliance must be used only for the purpose for which it was designed, namely as a heatpod for personal use. Any other use is considered not compliant and therefore dangerous.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Always use the Heat Pod inside the cover provided, as it heats up to 55 °C, and could cause a burn if placed on direct skin.
- The appliance is not to be used by people who are insensitive to heat or vulnerable and unable to react to overheating.


-  **DO NOT** pull the power cable or the appliance itself to remove the plug from the socket.
- **Always disconnect the appliance from the mains supply before cleaning or performing maintenance and when the appliance is not in use.**
- **If the appliance is faulty or malfunctions, switch it off and do not tamper with it. Any repairs must only be carried out by an authorised technical service centre.**
- **If the power cable is damaged, it should be replaced by an authorised technical service centre, so as to prevent all risks.**
- **Inspect the appliance frequently to check for signs of wear and damage. If such signs are found or if the appliance has been used incorrectly, contact an authorised technical assistance centre before continuing to use it.**
-  **WARNING – NOT suitable for children under the age of 3. Children under the age of 3 must not use the appliance as they are unable to react in the event of overheating.**
-  **DO NOT** use the appliance if it is wet.
-  **DO NOT** use the appliance to keep animals warm.
- **The heat pod can be used to warm the bed, but it must be removed before going to sleep.**

SYMBOLS

	Protection class II		Off position
	Warning		On position
	Prohibited		

PRODUCT OVERVIEW AND FEATURES

[A] Product Overview



Features:

- | | |
|-----------------------|-----------------------------------|
| 1. Mains Plug | 5. Charger |
| 2. Specification | 6. Led charging display |
| 3. On/Off Switch | 7. Heat pod cover |
| 4. Heat pod connector | 8. Store charger when not in use. |

[B] Charging Heat Pod



USING THE HEAT POD

- Remove the heat pod from packaging, and unzip the cover.
- Connect the charger (5) to the heatpod connector (4).
- Plug into the mains (see diagram B).
- Switch the heat Pod on to | (3). The led lights up (6).
- The Heat Pod will charge for 5 minutes, and will automatically stop charging and begin to heat up.
- Place the heat Pod on a level surface whilst charging.
- The LED will go off once charged and is ready to use.
- Disconnect the charger (5) and unplug from mains.
- Zip up the cover. The heat pod will start to heat up.
- **Always place inside cover before use (C).**
- When not in use, you can store the charger inside the top section of the cover (8).


When the LED goes off, the ceramic inside the heat pod begins to transmit heat and the temperature of the heatpod will increase, within 5 minutes warmth will be felt.

The heat pod reaches a maximum temperature of 55°C and provides long lasting heat for over

2 hours, it will take around 4 hours to return back to room temperature.

When the heat pod has been charged, it must return back to room temperature before you can charge it up again.


TO DISCONNECT

- Select the off position  and disconnect the plug from the socket.

CLEANING AND MAINTENANCE









ATTENTION! Disconnect the power cord (1) from the mains and the Heat Pod before performing any type of maintenance.

- Let the appliance cool down.
- Use a damp cloth to clean the plastic parts.
- Dry thoroughly since moisture damages the internal parts of the appliance.
-  Do NOT use abrasive products as they would damage the surface.

The fabric cover is washable.

CARE INFORMATION FOR THE FABRIC COVER

 Wash in the washing machine at 40°C	 Do not iron
 Tumble-dry at less than 40°C	 Do not bleach
 Do not dry-clean	 Tumble dry on low settings

AFTER SALE ASSISTANCE

1. Pack it carefully.
2. Enclose your name, address and day time telephone number.
3. Give the reason why you are returning it.

EN

4. If within the guarantee period, state where and when it was purchased and include a valid proof of purchase (e.g. receipt).
5. Send it to our Service Centre at the address below.

SERVICE CENTRE

PO BOX 166 – MIDDLEWICH – CHESHIRE
– CW10 0ZU - Tel: 01606 837 222

E-mail: customerservice@imetec.co.uk
www.dreamlanduk.co.uk

REGULAR SERVICING

The appliance must be repaired at the manufacturer's Service Centre, the defective appliance, if under guarantee, must be sent to the Service Centre for replacement repairs with a proper receipt or invoice that attests the date of sale of purchase.

SERVICE CENTRE

PO BOX 166 – MIDDLEWICH – CHESHIRE
– CW10 0ZU - Tel: 01606 837 222

E-mail: customerservice@imetec.co.uk
www.dreamlanduk.co.uk

WARRANTY

This product is guaranteed for a period of 2 years from the date of purchase against material, mechanical and electrical defects. The warranty is binding if it is accompanied by a valid receipt of payment. This guarantee is only valid if the appliance is used solely for domestic purposes in accordance with the instructions provided that is not connected to an unsuitable electricity supply, dismantled, interfered with in any way damaged, through misuse, fair wear and tear. Under this guarantee we undertake to repair or replace free of charge any parts found to be defective. PLEASE NOTE, THE COST OF

A SAFETY INSPECTION IS NOT COVERED BY THIS GUARANTEE. A CHARGE WILL BE MADE IN RESPECT OF ANY PRODUCT RETURNED UNDER THIS GUARANTEE, WHERE NO FAULT IS FOUND.

This guarantee is offered as an extra benefit and does not affect your statutory rights as a consumer. This guarantee does not confer any rights other than those expressly set out above and in particular we shall not be liable for any indirect or consequential loss or damage. Nothing in this guarantee or the instructions relating to the product excludes, restricts or otherwise affects your statutory rights. In line with our policy of continuous development, we reserve the right to change this product, packaging and documentation without notice. If a defect appears and after checking that the heat pod is being used properly in accordance with the instructions, return it with a valid proof of purchase, as soon as possible to the manufacturer's Service Centre. This guarantee is valid in the UK only.

SERVICE CENTRE

PO BOX 166 – MIDDLEWICH – CHESHIRE
– CW10 0ZU - Tel: 01606 837 222

E-mail: customerservice@imetec.co.uk

www.dreamlanduk.co.uk

DISPOSAL



The product packaging consists of recyclable materials. Dispose of these in an environmentally appropriate manner.



In accordance with EU directive 2002/96/EC, the appliance must be disposed of properly at the end of its service life.

This involves the recycling of valuable substances contained within the appliance

EN

and reduces the impact on the environment. For more information, contact your local disposal company or the store where you purchased the appliance.

Dreamland

M1001854
0415 (MMYY)