

UK
CA CE RoHS

RECYCLING YOUR ELECTRICALS

The Waste Electrical and Electronic Equipment (WEEE) Directive requires UK distributors to maximise separate collection and environmentally friendly processing of WEEE.

UK distributors (including retailers) are required to provide a system which allows all customers buying new electrical equipment the opportunity to recycle their old items free of charge.

As a responsible retailer, we have met these requirements by offering all customers buying new electrical and electronic equipment free take-back of their old electricals on a like-for-like basis.



Lakeland
Alexandra Buildings, Windermere,
Cumbria, UK LA23 1BQ
Tel: +44(0)15394 88100 lakeland.co.uk

27773_150724_V1

LAKELAND

EXTRA LOUD TIMER INSTRUCTION MANUAL



Model: 27773

Instructions for Use

Press 'MIN/SEC' together to reset timer 00:00.

Press 'MIN' to select minutes.

Press 'SEC' to select seconds.

If you press and hold either the 'MIN' or 'SEC' button it will move through the values quickly.

Press '▶/■' to start. Press '▶/■' again to pause count down.

The alarm will sound, if the volume is on and the red light alert will flash when the timer reaches 00:00. Press any button to stop the alarm. When the alarm is muted, the light alert will still flash.

To count up: When the display is at 00:00 press 'START/STOP' to begin timing.

Adjustable Volume

Press the '🔊' to increase the volume of the alarm or to silence it completely.

Warning: Not suitable for small children. This product contains small magnetic parts that if swallowed could stick together and cause serious injuries. Seek immediate medical attention if magnet(s) are swallowed.

Battery changing instructions

- If the product stops working the batteries may need replacing.
- Lift off battery compartment cover.
- Place in 2 new batteries (AAA/LR03/1.5V) with correct polarity (+/-).
- Replace battery compartment cover.
- Safely dispose of the old batteries in suitable recycling facility.

Battery Safety Guidelines

- Be sure to insert batteries correctly (+/-).
- Batteries should be replaced by an adult.
- Never dispose of batteries in fire as this may cause them to explode, or attempt to disassemble the batteries.
- Do not mix old and new batteries (replace all batteries at the same time).
- Do not mix Alkaline, standard Carbon Zinc or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not charge non-rechargeable batteries.
- Always remove exhausted or dead batteries from the product.
- Remove batteries from the product, if not going to be used for a long time.
- Ensure the battery compartment is secure. If the battery compartment doesn't close securely, stop using the product and keep it away from children.
- Batteries are harmful if swallowed. If you think that batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- KEEP OUT OF REACH OF CHILDREN.