

# LAKELAND

## INSTRUCTION BOOKLET CITRUS JUICER



Model: 61400

# LAKELAND CITRUS JUICER

Thank you for choosing the Lakeland Citrus Juicer.

Please take a little time to read this booklet before you use your machine and keep it in a safe place for future reference.

The Citrus Juicer makes juicing easy. No squeezing or force is required, simply press your halved fruit onto the juicing cone to activate the motor. Fresh juice is filtered straight into the jug, ready to serve. Juice lemons and limes for cooking with the small juicing cone, or add the large cone and juice grapefruits and oranges for drinks. The 600ml jug has millilitre and fluid ounce increments for measuring, and an adjustable strainer to catch pulp and pips.


Here at Lakeland, our award-winning family-owned business still offers the same excellent quality, value for money and exceptional customer service as when we founded the company back in the 1960s.

Our products are hand-picked and thoroughly tested so you can be sure that everything you purchase will be a pleasure to use for many years to come.

## CONTENTS

|  |     |
|--|-----|
| Product features .....                           | 3   |
| Safety cautions .....                            | 4-5 |
| Using your Citrus Juicer for the first time..... | 6   |
| Instructions for use.....                        | 7   |
| Frequently asked questions .....                 | 8   |
| Care and cleaning.....                           | 9   |
| Technical information.....                       | 10  |
| Electrical connections .....                     | 10  |
| Recycling your electricals .....                 | 10  |

# PRODUCT FEATURES



## SAFETY CAUTIONS

Carefully read all the instructions before using the appliance and keep in a safe place for future reference. Always follow these safety cautions when using the appliance to avoid personal injury or damage to the appliance. This appliance should be used only as described in this instruction book.


- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised.
- Make sure your electricity supply matches the voltage shown on the appliance.
- Ensure all packaging materials and any promotional labels or stickers are removed from the appliance before the first use.
- Always inspect the appliance before use for noticeable signs of damage. Do not use if damaged or has been dropped. In the event of damage, or if the appliance develops a fault contact the Lakeland customer care team on 015394 88100.
- Do not use this appliance if the lead is damaged. Contact the Lakeland customer care team on 015394 88100.
- Always use the appliance on a dry, level, heat resistant surface.
- Unplug from the mains when not in use and before cleaning. To disconnect, turn the socket to "off" and remove the plug from the mains socket.
- Do not use any accessories or attachments with this appliance other than those recommended by Lakeland.
- To protect against fire, electric shock or personal injury, do not immerse cord, plug or base unit in water or other liquids.
- Do not leave the lead hanging over the edge of a kitchen table or worktop. Avoid contact between the lead and hot surfaces.
- For indoor use only.
- For domestic use only.
- This appliance should be used for preparation of drinks as described within the instructions for use that accompany it.

- Always ensure that your hands are dry before removing the plug from the mains socket. Never pull the plug out of the mains socket by its lead.
- To avoid injury or possible fire, do not cover the appliance when in use.
- Do not connect this appliance to an external timer or remote control system.
- An extension cable may be used with care. The electrical rating of the cable should be at least as great as the appliance. Do not allow the cable to hang over the edge of the worktop or touch any hot surfaces.
- This appliance complies with the basic requirements of Directives 2014/30/EU (Electromagnetic Compatibility) and 2014/35/EU (Low Voltage Directive).
- **WARNING:** A cut off plug inserted into a 3amp socket is a serious safety (shock) hazard. Ensure the cut off plug is disposed of safely.
-  **CAUTION:** The plastic bags used to wrap this appliance or the packaging may be dangerous. To avoid risk of suffocation, keep these bags out of reach of babies and children. These bags are not toys.
- Keep the Citrus Juicer, plug and lead away from hot ovens, electric and gas burners, flames and hot surfaces.
- The rotating juicing cone will change direction if too much pressure is applied to it with the fruit. Decrease the pressure you are applying to the cone immediately, and the cone will continue to rotate as normal in the other direction.
- Always switch off and unplug the appliance before changing the juicing cones or removing the jug from the base unit and motor.
- **DO NOT** put the base unit in the fridge.


# USING YOUR CITRUS JUICER FOR THE FIRST TIME

- Unpack the Citrus Juicer, remove all the packaging materials.
- Before first use, wipe the base unit and spindle with a clean damp cloth.
- Wash the jug, strainers, juicing cones and lid in hot soapy water, rinse and dry thoroughly.
- Make sure that all parts are clean and dry before assembling the product.


**WARNING:** Do not insert the plug into an electrical socket, or turn on the Citrus Juicer before you have fully assembled it.




1. Place the base unit on a flat surface near a socket.
2. Unfold the power cord to the desired length.




3. Slot the jug over the spindle with the handle above the arrow on the base, and turn the jug clockwise until it locks into place.



4. Place the upper strainer over the bottom strainer, with the strainer opener coming through the hole on the upper strainer handle and click together.



5. Place the adjustable strainer on top of the jug, with the strainer adjuster above the handle, so it sits inside the jug.



6. Place the small juicing cone on to the spindle, with the large juicing cone on top of the small juicing cone.

7. The Citrus Juicer is now ready to use.

## INSTRUCTIONS FOR USE

1. First select the cone for the fruit you are juicing. Remove lid, the large cone and juice lemons and limes with the small juicing cone. Put the large cone on top of the small cone to juice grapefruits and oranges.
2. Cut your citrus fruit in half. Plug in and switch on the Citrus Juicer at the socket.
3. The Citrus Juicer motor will automatically start when your halved fruit is pressed onto the juicing cone. Fruit should be juiced in short bursts of 5 second intervals. Allow the Citrus Juicer motor to rest for a few minutes after using the Citrus Juicer continuously for 3 minutes at one time.
4. When you ease pressure on the fruit, the Citrus Juicer will stop.
5. When juicing do not exceed the 600ml mark.
6. Always switch off and unplug the appliance before changing the juicing cones or removing the jug from the base unit and motor.
7. Turn the jug anti-clockwise and lift to remove from the base unit.

**WARNING:** No squeezing or force is required. The rotating juicing cone will change direction if too much pressure is applied to it with the fruit. Decrease the pressure you are applying to the cone immediately, and the cone will continue to rotate as normal in the other direction.

## FREQUENTLY ASKED QUESTIONS

**Question:** Why is the cone not turning?

**Answer:** Check the appliance is plugged in and switched on at the socket.

The small juicing cone is not properly fitted onto the end of the spindle.

Check to see if there is any fruit pips between the juicing cone and the strainer. Remove the juicing cone and strainer and clean.

**Question:** Why does the machine change juicing direction?

**Answer:** Too much pressure has been applied to the fruit and juicer. Decrease the pressure you are applying to the cone and it will continue to rotate as normal.

**Question:** How can I get more pulp and citrus bits in my juice?

**Answer:** To increase the amount of pulp and citrus bits, move the strainer adjuster to the large dot mark so that the opening in the strainer is fully open.

## CARE AND CLEANING

- Before the first use and after every use, clean each part thoroughly. Dried fruit pulp is difficult to remove.
- Periodically check all parts before reassembly.
- Always switch off and unplug the Citrus Juicer before cleaning.
- Wipe the base and spindle with a clean damp cloth. **Caution:** Never immerse the base unit in water or any other liquids.
- Do not use abrasive cleaners, bleaching agents or metal scourers on any parts. This will damage the Citrus Juicer.
- Wash the jug, strainer, juicing cones and lid in hot soapy water, rinse and dry thoroughly.
- The jug can be taken off the base unit and used to serve juice, or store in the fridge.
- Make sure that the Citrus Juicer and attachments are completely clean and dry before you store them.
- Store the Citrus Juicer with the power cable loosely coiled. Never wrap it tightly around the machine.

## TECHNICAL INFORMATION:

- Power: 25W.
- Voltage: 220-240V.
- Frequency: 50/60Hz.
- Flex length approx. 78cm. (30¾").

## ELECTRICAL CONNECTIONS

The appliance is fitted with a fused three-pin plug to BS1363 which is suitable for use in all homes fitted with sockets to current specifications.

### CHANGING THE 3 AMP FUSE

Use a 3 amp BS1362 fuse. Only BSI or ASTA approved fuses should be used. If you are unsure which plug or fuse to use, always refer to a qualified electrician.

**Note:** after replacing or changing a fuse on a moulded plug which has a fuse cover, the cover must be refitted to the plug; the appliance must not be used without a fuse cover. If lost, replacement fuse covers can be obtained from an electrical shop. This appliance complies with the following EU Directives: 2014/35/EU (Low Voltage Directive) and 2014/30/EU (EMC Directive).



## RECYCLING YOUR ELECTRICALS

Along with many other high street retailers, Lakeland has joined a scheme whereby customers can take their unwanted electrical products to recycling points set up around the country.

Visit [www.recycle-more.co.uk](http://www.recycle-more.co.uk) to find your nearest recycling point.





Lakeland  
Alexandra Buildings, Windermere, Cumbria, UK LA23 1BQ  
Tel: +44 (0)15394 88100 **lakeland.co.uk**