



N^Scessity[®]

Instruction Manual

Midi Dehumidifier NSMDH-1608

Please register your product on-line at www.nscosity.co.uk



www.nscosity.co.uk

IMPORTANT!
KEEP FOR FUTURE
REFERENCE

Necessity®

Mini Dehumidifier


Model: NSMDH-1608

Package Contents

- a) 1 x Mini Dehumidifier b) 1x 12V DC Adaptor c) 1 x water pipe
d) This instruction manual

- If you find any of the above is missing, please contact your retailer or call our Helpline on 0870 765 2574.

Parts Description





Safety Instructions

Please read this instruction manual before using your Midi Dehumidifier for the first time and keep safe for future reference.

When using electrical appliances, basic safety precautions should always be followed:

- 1 Always use appliance in accordance with the instructions.
- 2 Please ensure that the rated voltage of your Dehumidifier corresponds to your electric system before connecting to the mains.
- 3 Always keep the device out of reach of children.
- 4 Do not allow children to play with any packaging, such as plastic bags.
- 5 Always check the product for damage before use.
- 6 Repairs may only be carried out by an authorised service centre; incorrect handling and faulty repairs may lead to danger.
- 7 If the product malfunctions, or has been dropped or damaged in any way, return the complete product to an authorised service facility for checking and repair.
- 8 This product is intended for domestic use only and not for commercial, industrial or outside use.
- 9 Always turn off the unit and unplug before moving it to empty the water tank. Always use both hands to carry this product.
- 10 To disconnect from the power supply, grip the plug and pull it from the power socket. Never pull by the cord.
- 11 Do not handle the Power Supply Cord with wet hands. An electrical shock may result.
- 12 Do not operate the unit in areas where petrol, paint, or other flammable liquids are used or stored.
- 13 Do not use the unit in artificially hot or humid conditions or allow it to be used in any hazardous environment.
- 14 Do not place the unit near an open flame, cooking/heating appliance or direct sunlight/hot surface.
- 15 Never place the unit in an area where it may fall into a bath or other water container. Always use on a dry, level surface.
- 16 Do not allow water to run inside the motor housing as this could result in a fire or electric shock.
- 17 Do not let the power cord hang over the edge of a table or counter. Arrange the power cord away from an area where it may be tripped over.
- 18 Never place the power cord under a carpet or rug.
- 19 Do not put objects on the product or allow objects to obstruct the air inlet or outlet openings.
- 20 Do not place directly on wooden, delicate or soft furniture ~ to protect surfaces place a mat or tray underneath your dehumidifier.
- 21 The use of attachments or accessories that are not sold with the product are not recommended as they may cause injury and void the warranty.
- 22 Do not attempt to repair or dismantle the unit yourself other than to clean the water tank. As described on page 5. Unskilled repairs will result in loss of warranty and could endanger the user or their property.
- 23 Place the unit 90cm above floor level for best performance. The unit should never be used at floor level if the room is carpeted.
- 24 Use only with the supplied adaptor.
- 25 Do not connect the unit to a power outlet using an extension cord.
- 26 This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 27 If the supply cord is damaged, it must be replaced by a service engineer in order to avoid a hazard.

Introduction

Congratulations on your purchase of the NScessity Midi Dehumidifier NSMDH-1608 which is designed to remove excess moisture from small enclosed spaces such as small bedrooms, wardrobes or storage cupboards.

Should your Midi Humidifier not work correctly or you have any questions about its operation, please visit our website at www.nscosity.co.uk or call our helpline on 0870 765 2574.

Operating Instructions

- Connect the adaptor to the main unit (the connection is on the left side of the unit).
- Check the water tank is inserted correctly.
- Insert the DC plug into the power supply socket.
- Press the Power Switch to "On". The green power supply indicator will light up and the unit will start to work.
- To turn off the unit press Power Switch to 'Off' position. The green light indicator will switch off and the unit will stop.




Water Removal:

- A red light will switch on to indicate the tank is full.
- When the water tank is full, the unit will switch off automatically.
- Before you empty your tank switch off the unit (press the Power switch to 'Off') and disconnect from the mains.
- Hold the unit steady and gently grip the water tank pulling and removing from the unit.
- To empty the tank, remove the lid on the water tank or pull the grey rubber plug from the back of the tank and dispose of the water into a sink or other water container.
- Replace the plug and lid to the water tank, and return to the unit. Make sure it is fitted securely. The unit will only function properly if the water tank is correctly positioned.
- Press the power switch to 'On' to restart.

Water Pipe (continuous disposal/option):

Should you wish to use the option of continuous disposal the water will be continuously removed through an overflow pipe (supplied) please follow the instructions below:

- Remove the grey rubber plug and attached the water pipe (supplied) into place. Ensure that the other end of the water pipe is lower than the unit to allow it to drain freely into a waste pipe or drainage system.
- When the water tank is full excess water will flow out via the water pipe and into the drainage system of your choice.
- When the water pipe is in use, the 'TANK FULL' light will not function. The unit will operate continuously until turned off.
- Empty and clean the tank at regular intervals to avoid water becoming stagnant and the build up of bacteria.





Cleaning & Maintenance

- Before you clean the appliance, switch off the unit and disconnect from the power supply.
- Do not spray with water, immerse in water, or use abrasive cleaning, liquids or chemical agents (Alcohol, Gasoline etc.) to clean the appliance as these may damage the surface.
- Use a damp cloth to clean the product housing.
- Do not allow water to leak into the internal parts of the unit.

Cleaning the water tank

If your water tank is not cleaned and disinfected on a regular basis, the water may become slimy and may develop an odour. This probably means that there is bacteria build up. Therefore once you have cleaned the water tank of your Dehumidifier, it should be disinfected/sterilised.

- Remove the water tank from the unit (as explained in operating instructions above).
- Remove lid/rubber plug and drain water if needed.
- Rinse out with clean water by removing the water tank and the water tank lid. Once the water tank has been cleaned with water, wipe the unit dry.
- Replace lid/rubber plug, wipe away any excess water from the surface of the tank.
- Reposition water tank securely in the main unit.

Disinfection of the Water Tank

- Fill the base with clean water and sterilisation fluid (or tablet) – available from most chemists and hardware stores.
- Allow this solution to soak as directed on the pack. Occasionally, gently swish the solution so it covers the tank evenly.
- Once soaking time has passed, pour the solution down the drain, being careful not to spill any.
- Rinse the base several times until the odour has dissipated. Never allow any solution to remain in your humidifier.

⚠ WARNING

- Do not switch on the dehumidifier while the sterilisation solution is in the water tank.
- Rinse the tank thoroughly with clean water and dry it before reusing the device.
- Do not immerse the main unit in water.

Storage

If the unit is not going to be used for a long period of time, we recommend:

- Cleaning it as detailed above.
- Air dry thoroughly before storing.
- Ensure the power adaptor is safely stored with the unit.
- Store in its original packaging in a cool, dry, dust free area away from heat sources & direct sunlight.

Note: Do not store the unit until it is completely dry. Failure to do so may cause bacteria, mould spores and fungus to grow & multiply in any residual dampness.

Troubleshooting

Problem	Possible Cause	Solution
The dehumidifier doesn't work	<ul style="list-style-type: none"> • Is it plugged in? • Is the water tank fitted correctly? • Is the water tank full • Is the temperature below 5°C 	<ul style="list-style-type: none"> • Check connection to unit and mains • Position tank correctly in the unit • Empty tank • The unit cannot operate effectively at temperatures below 5°
The dehumidifier doesn't seem to perform	<ul style="list-style-type: none"> • Is the air inlet or outlet blocked? • The humidity may already be low in the room 	<ul style="list-style-type: none"> • Clean outlets • Dehumidification is not necessary
Tank full indicator always on	<ul style="list-style-type: none"> • The water tank may be full or not fitted properly 	<ul style="list-style-type: none"> • Remove tank from unit and empty it or re-adjust as necessary
The unit is leaking	<ul style="list-style-type: none"> • Tank could be damaged • The surface may be uneven 	<ul style="list-style-type: none"> • Check the tank is in good condition & not cracked • Check unit is on a level surface
The unit is very noisy	<ul style="list-style-type: none"> • Uneven surface 	<ul style="list-style-type: none"> • Ensure the unit is placed on a level surface

Recycling and Disposal

The WEEE directive (Waste Electrical and Electronic Equipment; 2002/96/EC) has been put in place to ensure that products are recycled using best available treatment, recovery and recycling techniques to ensure human health and high level environment protection. Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



Do not mix products bearing the crossed out bin symbol with your general household waste. Please recycle where facilities exist.

Check with your Local Authority or retailer for recycling advice.



Service and Warranty

- Do not use any product that has been damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- For your convenience, record the date you received the product below, and attach your purchase receipt docket as proof of purchase.
- To ensure your product is covered by warranty, the complete product together with your purchase receipt should be returned to your retailer.

NScosity guarantees this product free from defects in materials and workmanship for a period of one (1) year. Should this unit be operated under conditions other than those recommended or any attempts made to modify the unit or if the product has been re-sold, this will render the WARRANTY VOID.

The product you buy may sometimes differ slightly from the illustration. This warranty is in addition to, and does not affect, your statutory rights.

**Should you have a problem with this product,
please contact our help desk on Tel: 0870 765 2574
or visit our website at www.NScosity.co.uk**

This product has been manufactured to comply with
CE directives 2006/95/EC & 2004/10B/EC

Date of purchase:	
Place of purchase:	

NScosity has a large range of premium products.
We endeavour to ensure NScosity Products are the
best you can get in their categories, we are very proud
of them! Please visit our website for further information,
www.NScosity.co.uk





Nsc
essentials



Specification

Model No:	NSMDH-1608
Voltage Frequency:	230V ~ 50Hz
Power:	65W
Output :	DC12V
Tank capacity:	2.2L
Extraction rate:	max 600ml/day (30% / 80% RH)
Weight:	2.1kg
Dimensions:	360 x 230 x 140 mm



NscEssity®

Tel: 0870 765 2574

www.nscEssity.co.uk

GU8 6BD

NSMDH-1608 /IM/1011

Copyright © NscEssity. All rights reserved

