

TO USE:

Place racks etc. into the bottom corner of the cleaning bag ensuring you do not puncture it in any way.

Pour the gel into the bag with enough solution to enable the racks to have a complete coating when the bag is flat. Before sealing, get as much air as possible out of the bag then close the seal then fold over to make the smallest envelope to ensure all the racks are coated. Leave for 2 hours and turn over to recoat with the gel. When left always leave in a safe place where the bag can't be interfered with. Best results are achieved if left overnight.

WASHING DOWN AFTER SOAKING:

Remove racks etc. from the cleaning bag rinse carefully with hot soapy water and then with hot water only, dry and return to oven or bbq. The remaining gel and debris can be washed down the sink by using hot water whilst rinsing the bag at the same time.

When empty the bag can be placed into your recycling box for plastics.

TAKE CARE:

- Avoid contact with eyes and skin.
- In case of contact with eyes or skin, rinse immediately with plenty of water and seek medical advice.
- If swallowed, do not induce vomiting; seek medical advice immediately and show this container or label.
- Keep locked up and out of the reach of children.

RDi INTERNATIONAL LTD

UNIT 4 · PARK FARM · CM77 8JX

TEL: 01376 333550

www.ovenmate.co.uk

Oven Mate is RDi's registered trademark

**Just For Racks**

Makes rack cleaning easy



Pour in bag solution
with resealable cleaning bag

Eco Friendly Formulation

Just For Racks

The safe way to soak and cleanse your appliance with our resealable poly bag.

Please adhere to all instructions in particular those referring to safety. Keep this container out of reach from children & animals.

Our non caustic gel formula can be used on most surfaces if soaked for 2 hours. All internal oven fittings can be left overnight if required for best results with stubborn debris.

Our unique formula is not corrosive but if spilled accidentally wipe up immediately with a damp cloth.

Important: Wear suitable rubber gloves to protect hands when using this product.

Always ensure when inserting racks, shelves or sides of the oven you do not puncture the resealable cleaning bag.

Do not insert any items if hot.

To remove racks etc. after cleaning, move them towards the seal before opening, open seal then remove carefully before rinsing.

Repeat the procedure for stubborn stains or large build up of debris.


For deep cleaning of the actual oven please use our multi award winning and widely available Oven Mate Cleaning Gel.



IRRITANT

500ml e

Contains:
Less than 5%
monoethanolamine

**TO USE:**

Place racks etc. into the bottom corner of the cleaning bag ensuring you do not puncture it in any way.

Pour the gel into the bag with enough solution to enable the racks to have a complete coating when the bag is flat. Before sealing, get as much air as possible out of the bag then close the seal then fold over to make the smallest envelope to ensure all the racks are coated. Leave for 2 hours and turn over to recoat with the gel. When left always leave in a safe place where the bag can't be interfered with. Best results are achieved if left overnight.

WASHING DOWN AFTER SOAKING:

Remove racks etc. from the cleaning bag rinse carefully with hot soapy water and then with hot water only, dry and return to oven or bbq. The remaining gel and debris can be washed down the sink by using hot water whilst rinsing the bag at the same time.

When empty the bag can be placed into your recycling box for plastics.

TAKE CARE:

- Avoid contact with eyes and skin.
- In case of contact with eyes or skin, rinse immediately with plenty of water and seek medical advice.
- If swallowed, do not induce vomiting; seek medical advice immediately and show this container or label.
- Keep locked up and out of the reach of children.

RDi INTERNATIONAL LTD

UNIT 4 · PARK FARM · CM77 8JX

TEL: 01376 333550

www.ovenmate.co.uk

Oven Mate is RDi's registered trademark

**Just For Racks**

Makes rack cleaning easy



Pour in bag solution
with resealable cleaning bag

Eco Friendly Formulation

Just For Racks

The safe way to soak and cleanse your appliance with our resealable poly bag. Please adhere to all instructions in particular those referring to safety. Keep this container out of reach from children & animals.

Our non caustic gel formula can be used on most surfaces if soaked for 2 hours. All internal oven fittings can be left overnight if required for best results with stubborn debris.

Our unique formula is not corrosive but if spilled accidentally wipe up immediately with a damp cloth.

Important: Wear suitable rubber gloves to protect hands when using this product

Always ensure when inserting racks, shelves or sides of the oven you do not puncture the resealable cleaning bag.

Do not insert any items if hot.

To remove racks etc. after cleaning, move them towards the seal before opening, open seal then remove carefully before rinsing.

Repeat the procedure for stubborn stains or large build up of debris.

For deep cleaning of the actual oven please use our multi award winning and widely available Oven Mate Cleaning Gel.



IRRITANT

250ml e

Contains:
Less than 5%
monoethanolamine